

Unit	Year	Make	Style	\$359.00
Ford # F-2011	2011-current	Ford	Super Duty NO DRILL	(³ / ₄ & 1 ton)
# 2408	F 2008-2010	Ford	Super Duty	³ / ₄ & 1 ton
# 2458	F '99-2007	Ford	Super Duty	³ / ₄ , & 1 Ton (1/2 ton '99-03, not '04 and later)
# 2012	F '80-98	Ford	Old body style	³ / ₄ & 1 Ton

*** Ford crossover years are 1997-2002

Ford/Chev				
# 1053	F '97-02	Ford	Ford light duty	(¹ / ₂ , ³ / ₄ , & 1 Tons)
	C '88-01	Chevy/GMC	Chevy/GMC old body	(" " " ")

Chevy				
# C-2011	2011-current	Chevy/GMC	NO DRILL	(³ / ₄ & 1 ton)
# 1172	C '99-2010	Chevy/GMC	New body style	³ / ₄ , & 1 Tons (will fit ¹ / ₂ tons thru '07, must turn center plate backwards, NOT 08-tube frm.)

***Chevy/GMC crossover years are 1999-2001

Dodge				
# 2172	D '03-current	Dodge	³ / ₄ & 1 Ton tube frame & ¹ / ₂ ton Mega Cab only.	
			NO DRILL	('03-'08 ¹ / ₂ tons require 6 ¹ / ₂ " clamp bolts, Will not fit '09 & newer due to coil springs)
# 1165	D '94-02	Dodge	³ / ₄ & 1 Ton(1/2 tons, but no holes are in frame)	
# 1000	Flatbed Kits	Any	Any (weld in)	

Additional products:

Description	Size	Additional info.
Flatbed Kit (#1000)	Standard	Weld in
Flatbed Kit (#1000T)	Tall ball	Weld in
Tall shank ball	2 5/16"	1 1/4" shank
Standard shank ball	2 5/16"	5/8" shank
Brackets	Any	
Center Plate	Standard	
Wedge (lock)	Standard	
Offset	5" setback	18K
5 th Wheel RV hitch	18K cap.	